

CARSON PRO[®]

LIGHTFLEX™ LF-10

Instructions for Use:

- Attach task lamp to flat metal surface using built-in magnet located in magnifier base (Fig. 1).
- To use with table clamp, attach clamp to table and tighten securely (Fig 2). Attach task lamp to top portion of clamp using built-in magnet located in magnifier base (Fig. 3).
- Plug in power adapter to standard wall outlet and insert plug into power jack located on the left side of the magnifier base (Fig. 4).
- To use with battery power, remove the plug from the power jack. The unit will automatically switch to battery power.
- Position task lamp head as desired. Turn on light using switch located on the front of the task lamp base (Fig. 5).

To change batteries:

- Remove battery door and then remove battery case from compartment (Fig. 6-7).
- Replace exhausted batteries with 4 fresh AA 1.5V batteries according to polarity indicators printed inside case.
- Place loaded battery case into battery compartment with metal contacts facing upwards and towards the inside of the battery compartment (Fig. 8).
- Replace battery door when finished.

Caution: Do not look at the LED light directly to avoid harming your eyes.

